



EVEKTOR - AEROTECHNIK a.s.

Letecká 1384
686 04 Kunovice
CZECH REPUBLIC

Tel.: +420572 537 111
Fax: +420 572 537 900
email: marketing@evektor.cz

AIRCRAFT OPERATING INSTRUCTIONS

FOR

SportStar plus

LIGHT SPORT AIRCRAFT

Serial number: **2007 0928**

Registration mark: **N928MF**

Document number: **SP2006AOIUS**

Date of issue: **December 20, 2006**

This manual must be on the airplane board during operation. This manual contains information which must be provided to the pilot and also contains supplementary information provided by the airplane manufacturer - Evektor - Aerotechnik a.s.

This aircraft must be operated in compliance with the information and limitations stated in this manual.



CONTENTS

0.	<i>TECHNICAL INFORMATION</i>	3
0.1	Log of Revisions	3
0.2	List of Effective Pages	5
0.3	AOI Sections	8



Intentionally left blank



0. TECHNICAL INFORMATION

0.1 Log of Revisions

All revisions or supplements to this manual, except actual weighing data, are issued in form of revisions, which will have new or changed pages as appendix and the list of which is shown in the Log of Revisions table.

The new or changed text in the revised pages will be marked by means of black vertical line on the margin of page and the revision number and date will be shown on the bottom margin of page.

Rev. No.	Affected Section	Affected Pages	Date	Approved	Date	Date of Insertion	Sign.



AIRCRAFT OPERATING INSTRUCTIONS

Doc. No. SP2006AOIUS

[illegible]



0.2 List of Effective Pages

Section	Page	Date	Section	Page	Date
-	Title page	-	2	2-1	Dec 20/06
				2-2	Dec 20/06
0	0-1	Dec 20/06		2-3	Dec 20/06
	0-2	Dec 20/06		2-4	Dec 20/06
	0-3	Dec 20/06		2-5	Dec 20/06
	0-4	Dec 20/06		2-6	Dec 20/06
	0-5	Dec 20/06		2-7	Dec 20/06
	0-6	Dec 20/06		2-8	Dec 20/06
	0-7	Dec 20/06		2-9	Dec 20/06
	0-8	Dec 20/06		2-10	Dec 20/06
				2-11	Dec 20/06
				2-12	Dec 20/06
1	1-1	Dec 20/06			
	1-2	Dec 20/06			
	1-3	Dec 20/06	3	3-1	Dec 20/06
	1-4	Dec 20/06		3-2	Dec 20/06
	1-5	Dec 20/06		3-3	Dec 20/06
	1-6	Dec 20/06		3-4	Dec 20/06
	1-7	Dec 20/06		3-5	Dec 20/06
	1-8	Dec 20/06		3-6	Dec 20/06
	1-9	Dec 20/06		3-7	Dec 20/06
	1-10	Dec 20/06		3-8	Dec 20/06
				3-9	Dec 20/06
				3-10	Dec 20/06



Section	Page	Date	Section	Page	Date
4	4-1	Dec 20/06	5	5-12	Dec 20/06
	4-2	Dec 20/06		5-13	Dec 20/06
	4-3	Dec 20/06		5-14	Dec 20/06
	4-4	Dec 20/06		5-15	Dec 20/06
	4-5	Dec 20/06		5-16	Dec 20/06
	4-6	Dec 20/06			
	4-7	Dec 20/06			
	4-8	Dec 20/06			
	4-9	Dec 20/06	6	6-1	Dec 20/06
	4-10	Dec 20/06		6-2	Dec 20/06
	4-11	Dec 20/06		6-3	Dec 20/06
	4-12	Dec 20/06		6-4	Dec 20/06
	4-13	Dec 20/06		6-5	Dec 20/06
	4-14	Dec 20/06		6-6	Dec 20/06
	4-15	Dec 20/06		6-7	Dec 20/06
	4-16	Dec 20/06		6-8	Dec 20/06
	4-17	Dec 20/06		6-9	Dec 20/06
	4-18	Dec 20/06		6-10	Dec 20/06
				6-11	Dec 20/06
				6-12	Dec 20/06
				6-13	Dec 20/06
				6-14	Dec 20/06
5	5-1	Dec 20/06			
	5-2	Dec 20/06			
	5-3	Dec 20/06			
	5-4	Dec 20/06			
	5-5	Dec 20/06			
	5-6	Dec 20/06			
	5-7	Dec 20/06			
	5-8	Dec 20/06			
	5-9	Dec 20/06			
	5-10	Dec 20/06			
	5-11	Dec 20/06			

[illegible]



0.3 AOI Sections

	Section
GENERAL	1
LIMITATIONS	2
EMERGENCY PROCEDURES	3
NORMAL PROCEDURES	4
PERFORMANCE	5
WEIGHT AND BALANCE	6
AIRPLANE AND SYSTEM DESCRIPTION	7
AIRPLANE HANDLING, SERVICING AND MAINTENANCE	8
SUPPLEMENTS	9



CONTENTS

1. GENERAL	3
1.1 Introduction	3
1.2 Certification basis	3
1.2.1 Data location.....	4
1.3 Warnings, cautions, notes.....	4
1.4 Descriptive data	5
1.4.1 Airplane description.....	5
1.4.2 Powerplant.....	5
1.4.3 Main technical data	6
1.4.4 Three-view drawing.....	7
1.5 Definitions and abbreviations	8



Intentionally left blank



1. GENERAL

1.1 Introduction

PARTICIPANT'S RESPONSIBILITY

There are inherent risks in participating in aviation activities, these risks are significant, up to and potentially including death. Operators and passengers of recreational aviation aircraft, by participation, accept the risks inherent in such participation of which the ordinary prudent person is or should be aware. Pilots and passengers have a duty to exercise good judgment and act in a responsible manner while using the aircraft and to obey all oral or written warnings, or both, prior to and/or during use of the aircraft.

This Flight manual has been prepared to provide pilots and instructors with information for safe and efficient operation of the SPORTSTAR^{PLUS} airplane. It also contains supplementary information considered to be important by the airplane manufacturer.

1.2 Certification basis

The aircraft described herein complies with the Standard Specification for Design and Performance of a Light Sport Airplane, Designation F 2245-04, issued by ASTM International Committee F37.

This type of aircraft complies with the Czech UL-2 airworthiness requirements, it has been type certified by the Light Aircraft Association of the Czech Republic and the type certificate ULL 07/2003 supplement was issued in December 19th, 2006.



1.2.1 Data location

The certification documentation is available from the US General importer or airplane manufacturer on a request of competent aviation authority and/or Designated Airworthiness Representative.

Contact address:

US General Importer:
Sport Aircraft International LLC
804 Water Street
Kerrville, Texas 78028
USA
phone.: 001 830 896 8910
fax: 001 830 896 8913
e-mail: sportac@ktc.com

Airplane Manufacturer:
Evektor - Aerotechnik, a.s.
Letecká 1384
686 04 Kunovice
Czech Republic
tel.:+420 572 537 111
fax:+420 572 537 900
e-mail:marketing@evektor.cz

1.3 Warnings, cautions, notes

The following informations apply to warnings, cautions and notes used in the Aircraft Operating Instructions:

WARNING

MEANS THAT NON-OBSERVATIONS OF THE CORRESPONDING PROCEDURE LEADS TO AN IMMEDIATE OR IMPORTANT DEGRADATION OF THE FLIGHT SAFETY.

CAUTION

MEANS THAT NON-OBSERVATIONS OF THE CORRESPONDING PROCEDURE LEADS TO A MINOR OR TO A MORE OR LESS LONG TERM DEGRADATION OF THE FLIGHT SAFETY.

NOTE

Draws the attention to any special item not directly related to safety but which is important or unusual.



1.4 Descriptive data

1.4.1 Airplane description

SPORTSTAR^{PLUS} airplane is an all-metal low-wing of semimonocoque structure with two side by side seats and nose wheel landing gear

For further description see Section 7 - Airplane and system description.

1.4.2 Powerplant

The standard powerplant consists of ROTAX 912ULS (100 hp) engine and WOODCOMP KLASSIC 170/3/R propeller.

For further description see Section 7 - Airplane and system description.

For concrete engine and propeller type - see Section 9 - Supplements - Airplane description.



1.4.3 Main technical data

Wing

Span	28.37 ft
Area	112.7 sq.ft
MAC depth	4.1 ft
Wing loading	10.76 lbs/sq.ft
Aileron - area	2.62 sq.ft
Flap - area	5.60 sq.ft

Fuselage

length	19.62 ft
width	3.55 ft
height	7.66 ft
cockpit canopy max. width	3.87 ft

Horizontal tail unit

Span	8.20 ft
HTU Area	20.88 sq.ft
Elevator area	8.40 sq.ft

Vertical tail unit

Height	4.07 ft
VTU Area	10.76 sq.ft
Rudder area	4.31 sq.ft

Landing gear

Wheel track	6.12 ft
Wheel base	4.43 ft
Main and nose landing gear wheel diameter	14 in



AIRCRAFT OPERATING INSTRUCTIONS

Doc. No. SP2006AOIUS

1.4.4 Three-view drawing




Figure 1-1



1.5 Definitions and abbreviations

NOTE

The abbreviations on placards in the airplane cockpit, are printed in **BOLD CAPITAL LETTERS** in the text of this Aircraft Operating Instructions.

ACCU	accumulator
ALT ENC	encoding altimeter
ATC	air traffic control
bar	bar 1 bar = 100 kPa
BEACON	anti-collision beacon
°C	Celsius degree
CAS	calibrated airspeed
CLOCK	aircraft clock
ft	foot 1 ft = 0.305 m
GPS	global positioning system
HTU	horizontal tail unit
IAS	indicated airspeed
IC	intercom
IFR	instrument flight rules
ISA	international standard atmosphere
kg	kilogram
KIAS	indicated air speed in knots
KCAS	calibrated airspeed in knots
mph	mile per hour
mph CAS	calibrated airspeed in miles per hour
km/h CAS	calibrated airspeed in km/h
kts	knots 1 kt = 1.852 km/h
litres	litre
lbs	pounds 1 lb = 0.45 kg
m	meter
MAC	mean aerodynamical chord
max.	maximum
min.	minimum or minute
mm	millimeter
m/s	meter per second
OAT	outside air temperature

**AIRCRAFT OPERATING INSTRUCTIONS**Doc. No. SP2006AOIUS

OFF position	system is switched off or control element is in off-
ON position	system is switched on or control element is in on-
Pa	pascal $1\text{Pa} = 1\text{N/m}^2$
PSI	pound per sq.in ($1\text{PSI} = 6.89\text{ kPa}$)
RPM	revolutions per minute
RWY	runway
sq.ft	foot squared
sq.m	meter squared
V_A	manoeuvring airspeed
V_{FE} position	maximum flap extended speed - flaps in 50°
VFR	visibility flight rules
V_{LOF}	airplane lift-off speed
V-METER	voltmeter
V_{NE}	never exceed speed
V_{NO}	maximum structural cruising speed
V_{SO}	stall speed with wing flaps in 50° position
V_{S1}	stall speed with wing flaps in 0° position
VTU	vertical tail unit
V_X	best angle-of-climb speed
V_Y	best rate-of-climb speed
XPDR	transponder



Intentionally left blank



CONTENTS

2. LIMITATIONS	3
2.1 Introduction	3
2.2 Airspeed	3
2.3 Airspeed indicator marking	4
2.4 Powerplant.....	5
2.5 Powerplant instrument marking.....	6
2.6 Miscellaneous instrument marking.....	6
2.7 Weight.....	6
2.8 Centre of gravity.....	7
2.9 Approved manoeuvres	7
2.10 Manoeuvring load factors.....	7
2.11 Flight crew	7
2.12 Kinds of operation	8
2.13 Fuel	8
2.14 Oil.....	9
2.15 Maximum number of passengers	9
2.16 Other limitations.....	10
2.17 Limitation placards	10



Intentionally left blank



2. LIMITATIONS

2.1 Introduction

Section 2 contains operation limitation, instrument marking and basic placards necessary for safe operation of airplane and its engine, standard systems and equipment. Limitation for optional systems and equipment are stated in section 9 - Supplements.

2.2 Airspeed

Airspeed limitations and their meaning for operation are stated in the table below:

Speed		KIAS	mph IAS	Meaning
V _{NE}	Never exceed speed	146	168	Do not exceed this speed in any operation.
V _{NO}	Maximum structural cruising speed	105	121	Do not exceed this speed, with exception of flight in smooth air, and even then only with increased caution.
V _A	Manoeuvring speed	86	99	Do not make full or abrupt control movement above this speed, because under certain conditions the aircraft may be overstressed by full control movement.
V _{FE}	Maximum flap extended speed	70	81	Do not exceed this speed with the given flap setting.



2.3 Airspeed indicator marking

Airspeed indicator markings and their color-code significance are shown in the table below:

Marking	Range		Meaning
	KIAS	mph IAS	
Red line	38	44	V _{S0} at maximum weight (flaps in landing position 50°)
White arc	38 - 70	44 - 81	Operating range with extended flaps. Lower limit- V _{S0} at maximum weight (flaps 50°) Upper limit - V _{FE}
Green arc	43 - 105	50 - 121	Normal operation range Lower limit - V _{S1} at maximum weight (flaps 0°) Upper limit - V _{NO}
Yellow arc	105 - 146	121 - 168	Manoeuvres must be conducted with caution and only in smooth air
Red line	146	168	Maximum speed for all operations - V _{NE} .

**AIRCRAFT OPERATING INSTRUCTIONS**Doc. No. SP2006AOIUS

2.4 Powerplant

Engine manufacturer:	Bombardier-Rotax GMBH	
Engine type:	ROTAX 912ULS	
Power:	maximum take-off	100 HP
	maximum continuous	93.8 HP
Engine speed:	maximum take-off	5800 RPM max. 5 minutes
	maximum continuous	5500 RPM
	idle	1400 RPM
Cylinder head temperature:	maximum	275 °F
Oil temperature:	maximum	266 °F
	optimum operation	190 - 230 °F
Oil pressure:	maximum	102 PSI
	minimum	12 PSI
	optimum operation	29 - 73 PSI
Fuel pressure:	minimum	2.2 PSI
Fuel grades:	see 2.13,	
Oil grades:	see 2.14,	
Reducer gear ratio:	2.43 : 1	
Propeller manufacturer:	WOODCOMP s.r.o.	
Propeller type:	KLASSIC 170/3/R	
	3 blade, composite, on-ground adjustable	
Propeller diameter:	68 in	
Maximum prop speed:	2600 RPM	

NOTE

If installed a different propeller type - see section 9 - Supplements for propeller limitations.



2.5 Powerplant instrument marking

The colour-code of instruments is shown in the following table:

Instrument	Units	Red line	Green arc	Yellow arc	Red line
		Lower limit	Normal operation range	Caution range	Upper limit
RPM indicator	RPM	-	1400 - 5500	5500 - 5800	5800
Oil temperature indicator	°F	-	190 - 230	120 - 190 230 - 266	266
Oil pressure indicator	PSI	12	29 , 73	12 - 29 73 - 102	102
Cylinder head temperature	°F	-	-	-	275

2.6 Miscellaneous instrument marking

There are not other instruments with colour marking.

2.7 Weight

Empty weight (standard equipment)	695 lbs ± 2 %
Maximum take-off weight	1268 lbs
Maximum landing weight	1268 lbs
Maximum weight in baggage compartment	55 lbs

WARNING

DO NOT EXCEED MAXIMUM WEIGHTS! THEIR EXCEEDING LEADS TO AIRPLANE OVERLOADING AND TO DEGRADATION OF FLIGHT CHARACTERISTICS AND DETERIORATION OF MANOEUVRABILITY.

**AIRCRAFT OPERATING INSTRUCTIONS**Doc. No. SP2006AOIUS

2.8 Centre of gravity

Empty airplane C.G. position (standard equipment) 20 ± 2 %MAC

Operating C.G. range 20 to 34 %MAC

Reference datum is the wing leading edge.

2.9 Approved manoeuvres

SPORTSTAR^{PLUS} airplane is approved to perform the following manoeuvres:

- steep turns up to bank angle of 60°
- climbing turns
- lazy eights
- stalls (except for steep stalls)
- normal flight manoeuvres

WARNING

**AEROBATICS AS WELL AS INTENTIONAL
SPINS ARE PROHIBITED !**

2.10 Manoeuvring load factors

Maximum positive load factor 4.0

Maximum negative load factor -2.0

2.11 Flight crew

Minimum crew 1 pilot

Minimum weight of crew 121 lbs

Maximum weight of crew acc. to chapter 6.

WARNING

**DO NOT EXCEED MAXIMUM WEIGHTS! THEIR
EXCEEDING LEADS TO AIRPLANE
OVERLOADING AND TO DEGRADATION OF
FLIGHT CHARACTERISTICS AND
DETERIORATION OF MANOEUVRABILITY.**



2.12 Kinds of operation

The airplane is standardly approved for VFR daylight flights.

WARNING

NIGHT FLIGHTS ACCORDING TO VFR, FLIGHTS ACCORDING TO IFR (BY INSTRUMENTS) ARE APPROVED ONLY WHEN INSTRUMENTATION REQUIRED FOR SUCH FLIGHTS IS INSTALLED AND FLIGHT PERFORMED BY A PILOT WITH APPROPRIATE RATING! INTENTIONAL FLIGHTS UNDER ICING CONDITIONS ARE PROHIBITED.

Instruments and equipment for daylight flights according to VFR :

- 1 Airspeed indicator (the color marking according to par. 2.3)
- 1 Sensitive barometric altimeter
- 1 Magnetic compass
- 1 Fuel gauge indicator
- 1 Oil temperature indicator
- 1 Oil pressure indicator
- 1 Cylinder head temperature indicator
- 1 Engine speed indicator
- 1 Safety harness for every used seat

CAUTION

ADDITIONAL EQUIPMENT NECESSARY FOR AIRPLANE OPERATION IS GIVEN IN APPROPRIATE OPERATION REGULATION OF AIRPLANE OPERATOR'S COUNTRY.

2.13 Fuel

Fuel tank volume (each)	15.85 U.S. gallons
Total	31.7 U.S. gallons
Usable fuel	31.2 U.S. gallons
Unusable fuel	0.5 U.S. gallons (0.25 US gal per tank)

**AIRCRAFT OPERATING INSTRUCTIONS**Doc. No. SP2006AOIUS

NOTE

It is not recommended to fully tank the fuel tanks. Due to fuel thermal expansion keep about 2.11U.S. gallons of free space in the tank to prevent fuel bleed through the vents in the wing tips thus preventing environmental contamination. This should be adhered especially when cold fuel from an underground tank is tanked.

Approved fuel grades:

- automotive petrol with min RON 95
- EN 228 Premium
- EN 228 Premium plus
- AVGAS 100 LL

Due to higher lead content in AVGAS, the wear of valve seats and deposits in the combustion chamber and lead sediments in the lubrication system will increase. Therefore, use AVGAS only if you encounter problem with vapour lock or if the other fuel types are not available

For other suitable fuel types refer to the engine Operator's Manual

NOTE

Use only fuel suitable for the respective climatic zone.

Risk of vapour formation if using winter fuel for summer operation.

2.14 Oil

Performance classification SF, SG according to API

Oil volume:

- | | |
|-----------|-------------------|
| - minimum | 0.53 U.S. gallons |
| - maximum | 0.79 U.S. gallons |

2.15 Maximum number of passengers

Maximum number of passengers including pilot 2



2.16 Other limitations

SMOKING IS PROHIBITED on the airplane board.

PASSENGER NOTICE

This aircraft conforms to ASTM Consensus Standards of airworthiness developed and maintained by the aviation community under ASTM Technical Committee F37.

PASSENGER WARNING !

This aircraft was manufactured in accordance with Light Sport Aircraft airworthiness standards and does not conform to standard category airworthiness requirements.

2.17 Limitation placards

The following placards are located on the instrument panel:



The following placards are located on the the tilting canopy:

**PASSENGER NOTICE:
THIS AIRCRAFT CONFORMS TO ASTM
CONSENSUS STANDARDS OF AIRWORTHINESS
DEVELOPED AND MAINTAINED BY THE
AVIATION COMMUNITY UNDER ASTM
TECHNICAL COMMITTEE F37.**

**PASSENGER WARNING!
THIS AIRCRAFT WAS MANUFACTURED IN
ACCORDANCE WITH LIGHT SPORT AIRCRAFT
AIRWORTHINESS STANDARDS AND DOES NOT
CONFORM TO STANDARD CATEGORY
AIRWORTHINESS REQUIREMENTS.**

The following placards is located in the baggage compartment:



**AIRCRAFT OPERATING INSTRUCTIONS**

Doc. No. SP2006AOIUS

The following placards are located on the tilting canopy:

This Light Sport Aircraft has been approved only for VFR day flights under no icing conditions.	
Aerobatics and intentional spins are prohibited!	
AIRSPEED IAS	
Never exceed	146 kts
Manoeuvring	86 kts
Max. Flap Extended	70 kts
Stalling	38 kts
ENGINE SPEED	
Max. Take-off (max. 5 min.)	5800 rpm
Max. Continuous	5500 rpm
Idling	1400 rpm
Unusable quantity of fuel	0.5 USgal

This airplane has been approved only for VFR day flights under no icing conditions.	
Aerobatics and intentional spins are prohibited!	
AIRSPEED IAS	
Never exceed	168 MPH
Manoeuvring	99 MPH
Max. Flap Extended	81 MPH
Stalling	44 MPH
ENGINE SPEED	
Max. Take-off (max. 5 min.)	5800 rpm
Max. Continuous	5500 rpm
Idling	1400 rpm
Unusable quantity of fuel	0.5 USgal

Or

LOAD LIMITS						
Max.take-off weight		1268 lbs				
Empty weight		672 lbs				
Max.baggage weight		55 lbs				
PERMITTED CREW WEIGHT [lbs]						
Fuel quantity U.S.gal.		31,7	26,4	19,8	13,2	6,6
Baggage weight	max. 55 lbs	350	381	421	461	500
	1/2 26 lbs	378	410	450	489	529
	No baggage	405	437	476	516	556
Fuel reserve (1/8 on the fuel indicator)				2.1 U.S. gallons		

NOTE

The values stated on the placard “LOAD LIMITS” are valid for the empty weight of the airplane with standard equipment. The placard with values valid for the actual empty weight of the airplane will be placed in the cockpit.

Other placards and labels are shown in Aircraft Maintenance and Inspection Procedures.



Intentionally left blank



CONTENTS

3.	<i>EMERGENCY PROCEDURES</i>	3
3.1	Introduction	3
3.2	Speeds for performing emergency procedures	3
3.3	Engine failure	3
3.3.1	Engine failure at take-off run	3
3.3.2	Engine failure at take-off	3
3.3.3	Engine failure in flight.....	4
3.4	Engine starting at flight	4
3.5	Engine fire	5
3.5.1	Fire on the ground.....	5
3.5.2	Fire during take-off.....	5
3.5.3	Fire in flight	6
3.6	Fire in the cockpit (if manual extinguisher available aboard).....	7
3.7	Gliding flight.....	7
3.8	Emergency landing	8
3.8.1	Emergency landing - with non-operating engine	8
3.8.2	Safety landing- with engine operating	8
3.8.3	Landing with burst tire	9
3.8.4	Landing with damaged landing gear	9
3.9	Unintentional spin recovery	9
3.10	Other emergency procedures	10
3.10.1	Vibration	10
3.10.2	Carburettor icing	10





3. EMERGENCY PROCEDURES

3.1 Introduction

Section 3 describes operations and procedures for emergency situation solutions that could possibly occur during airplane operation.

3.2 Speeds for performing emergency procedures

Airspeed for the best gliding ratio (flaps retracted) 57 KIAS (66 mph IAS)

Precautionary landing (engine running, flaps in landing position - 50°) 53 KIAS (61 mph IAS)

Emergency landing (engine stopped, flaps in landing position - 50°) 53 KIAS (61 mph IAS)

3.3 Engine failure

3.3.1 Engine failure at take-off run

- | | |
|-------------------|--------------|
| 1. THROTTLE lever | idle |
| 2. Brakes | as necessary |
| 3. FUEL SELECTOR | OFF |
| 4. Ignition | OFF |
| 5. Master switch | OFF |

3.3.2 Engine failure at take-off

1. Gliding speed:
 - with flaps in take-off position (15°) min. 53 KIAS (61 mph IAS)
 - with flaps retracted (0°) min. 57 KIAS (66 mph IAS)
2. Altitude:
 - Land in take-off direction if below 150 ft:
 - Land in take-off direction or you can perform turn up to 90° if altitude is 150 - 400 ft:
 - You can try start engine if altitude is above 250 ft

Doc. No. SP2006AOIUS



7. THROTTLE lever
idle (choke opened)
or increased idle
(choke closed)

The propeller is rotating:

8. Ignition
BOTH

The propeller is not rotating:

9. Ignition
START
10. If engine starting does not occur, increase gliding speed up to 108 KIAS (124 mph IAS) (see NOTE), so that air-flow turns the propeller and engine will start.
11. Ignition
BOTH
12. If engine starting is unsuccessful, then continue according to paragraph 3.8.1 Emergency landing.

3.5 Engine fire

3.5.1 Fire on the ground

1. FUEL SELECTOR
OFF
2. Brakes
brake
3. THROTTLE lever
full
4. HOT AIR knob (if installed)
push
- After the engine stops:
5. Ignition
OFF
6. Master switch
OFF
7. Airplane
leave
8. Manual extinguisher (if available)
use

3.5.2 Fire during take-off

1. FUEL SELECTOR
OFF
2. THROTTLE lever
full
3. Airspeed
63 KIAS (73 mph IAS)
4. HOT AIR knob (if installed)
push



After the engine stops:

- | | |
|--|----------------------|
| 5. Gliding speed | 53 KIAS (61 mph IAS) |
| 6. Ignition | OFF |
| 7. Master switch | OFF |
| 8. Land | |
| 9. Airplane | leave |
| 10. Manual extinguisher (if available) | use |

3.5.3 Fire in flight

- | | |
|--------------------------------|----------------------|
| 1. FUEL SELECTOR | OFF |
| 2. THROTTLE lever | full |
| 3. HOT AIR knob (if installed) | close |
| 4. Gliding speed | 57 KIAS (66 mph IAS) |
| 5. Ignition | OFF |
| 6. ATC | report if possible |
| 7. Master switch | OFF |

NOTE

For extinguishing the engine fire, you can perform slip under assumption that you have sufficient altitude and time.

WARNING

AFTER EXTINGUISHING THE ENGINE FIRE START ENGINE ONLY IF IT NECESSARY TO SAFE LANDING. FUEL LEAK IN ENGINE COMPARTMENT COULD CAUSE FIRE AND FIRE COULD RESTORE AGAIN.

- | | |
|---|--|
| 8. If you start engine again, switch off all switches, switch on the Master switch, and then subsequently switch on only equipment necessary to safe landing. | |
| 9. Emergency landing | carry out according to paragraph 3.8.1 |
| 10. Airplane | leave |



11. Manual extinguisher (if available) use as needed

3.6 Fire in the cockpit (if manual extinguisher available aboard)

1. Fire source identify
2. Master switch in case that the source of fire is electrical equipment. OFF
3. Manual extinguisher use
4. After fire extinguishing aerate the cockpit
5. Carry out safety landing according to 3.8.2

WARNING

NEVER AGAIN SWITCH THE DEFECTIVE SYSTEM.

NOTE

If a defective electrical system circuit was detected as the fire source, then switch off appropriate circuit breaker and switch over Master switch to ON position.

3.7 Gliding flight

NOTE

Gliding flight can be used for example in case of engine failure.

Wing flaps position	Retracted (0°)	Take-off (15°)
Airspeed	57 KIAS (66 mph IAS)	53 KIAS (61 mph IAS)



3.8 Emergency landing

3.8.1 Emergency landing - with non-operating engine

- | | |
|-------------------|--|
| 1. Airspeed | 57 KIAS (66 mph IAS) |
| 2. Landing area | choose,
determine wind direction |
| 3. Safety harness | tighten up |
| 4. Flaps | landing position (50°) |
| 5. Airspeed | 60 KIAS (69 mph IAS) |
| 6. Radiostation | notify situation to ATC
(if possible) |
| 7. FUEL SELECTOR | OFF |
| 8. Ignition | OFF |
| 9. Master switch | OFF before touch
down |

3.8.2 Safety landing- with engine operating

- | | |
|---------------------|---|
| 1. Area for landing | choose, determine wind
direction, carry out passage flight
with speed of 59 KIAS
(68 mph IAS),
flaps in take-off position (15°) |
| 2. Radiostation | notify situation to ATC
(if possible) |
| 3. Safety harness | tighten up |
| 4. Flaps | landing position (50°) |
| 5. Airspeed | 60 KIAS (55 mph IAS) |
| 6. Landing | carry out |



3.8.3 Landing with burst tire

CAUTION

WHEN LANDING AT HOLDING, KEEP THE WHEEL WITH BURST TIRE ABOVE THE GROUND AS LONG AS POSSIBLE BY MEANS OF AILERONS. IN CASE OF NOSE WHEEL BY MEANS OF ELEVATOR.

1. At running hold airplane direction by means of foot control and brakes

3.8.4 Landing with damaged landing gear

1. In case of nose landing gear damage touch down at the lowest possible speed and try to keep the airplane on main landing gear wheels as long as possible
2. In case of main landing gear damage touch down at the lowest possible speed and if possible keep direction at running

3.9 Unintentional spin recovery

NOTE

The airplane has not, when using normal techniques of pilotage, tendency to go over to spin spontaneously.

Standard procedure of recovery from spin:

- | | |
|-------------------|---|
| 1. THROTTLE lever | idle |
| 2. Control stick | aileron - neutral position |
| 3. Pedals | kick the rudder pedal push against spin rotation direction |
| 4. Control stick | push forward and hold it there until rotation stops |
| 5. Pedals | immediately after rotation stopping, set the rudder to neutral position |
| 6. Control stick | recover the diving |



CAUTION

ALTITUDE LOSS PER ONE TURN AND
RECOVERING FROM THE SPIN IS 500 UP TO
1000 FT.

3.10 Other emergency procedures

3.10.1 Vibration

If abnormal vibrations occur on the airplane then:

1. Set engine RPM to the mode in which the vibrations are the lowest
2. Land on the nearest possible airport, possibly perform safety landing according to par. 3.8.2. Safety landing.

3.10.2 Carburettor icing

Carburettor icing happens when air temperature drop in the carburettor occurs due to its acceleration in the carburettor and further cooling by evaporating fuel. Carburettor icing mostly happens during descending and approaching for landing (low engine RPM). Carburettor icing shows itself by engine power decreasing and by engine temperature increasing.

Recommended procedure for engine power regeneration is as follows:

1. CARBURETTOR PREHEATER (if installed) ON
2. THROTTLE lever set idle and cruising
power again

NOTE

Ice coating in the carburettor should be removed by decrease and reincrease of engine power.

3. If the engine power is not successfully increased, then carry out landing at the nearest suitable airport or, if it is not possible, carry out precautionary landing according to par. 3.8.2 Precautionary landing.



CONTENTS

4.	<i>NORMAL PROCEDURES</i>	3
4.1	Introduction	3
4.2	Recommended speeds for normal procedures	3
4.2.1	Take-off	3
4.2.2	Landing	3
4.3	Assembly and disassembly	3
4.4	Pre-flight check	4
4.5	Normal procedures and checklist	8
4.5.1	Before engine starting	8
4.5.2	Engine starting	8
4.5.3	Before taxiing	10
4.5.4	Taxiing	10
4.5.5	Before take-off	10
4.5.6	Take-off	11
4.5.7	Climb	12
4.5.8	Cruise	13
4.5.9	Descent	14
4.5.10	Before landing	14
4.5.11	Balked landing	15
4.5.12	Landing	15
4.5.13	After landing	16
4.5.14	Engine shut-off	16
4.5.15	Airplane parking	17



Intentionally left blank



4. NORMAL PROCEDURES

4.1 Introduction

Section 4 describes operations and recommended procedures for normal operation of the airplane. Normal procedures following from system installation and optional equipment, which require supplementation of these Instructions, are shown in section 9 - Supplements.

4.2 Recommended speeds for normal procedures

4.2.1 Take-off

Climbing speed up to 50 ft (flaps in take-off pos. - 15°)	56 KIAS (65 mph IAS)
Best rate-of-climb speed V_Y (flaps in take-off pos. - 15°)	56 KIAS (65 mph IAS)
Best rate-of-climb speed V_Y (flaps retracted - 0°)	63 KIAS (73 mph IAS)
Best angle-of-climb speed V_X (flaps in take-off pos. - 15°)	53 KIAS (61 mph IAS)
Best angle-of-climb speed V_X (flaps retracted - 0°)	55 KIAS (63 mph IAS)

4.2.2 Landing

Approaching speed for normal landing (flaps in landing position - 50°)	60 KIAS (69 mph IAS)
---	----------------------

4.3 Assembly and disassembly

Description of assembly and disassembly is given in the SPORTSTAR^{PLUS} Aircraft Maintenance and Inspection Procedures.



4.4 Pre-flight check

Carry out pre-flight check according to the following procedure:




Figure 4-1 Scheme of airplane preflight check

WARNING

**CHECK BEFORE PRE-FLIGHT CHECK THAT
IGNITION IS SWITCHED OFF !**

NOTE

The word “condition”, used in procedures of pre-flight check, means visual check of surface, damage, deformation, scratches, attrition, corrosion, icing or other effects decreasing flight safety.



1. Left landing gear leg - check
 - landing gear leg attachment and condition
 - landing gear wheel condition
 - tire condition and inflation
 - condition and attachment of wheel covers, mudguards (if installed)
2. Left wing - check
 - wing surface condition
 - leading edge condition
 - landing light condition - if installed
 - condition of the Pitot tube
 - draining of fuel tank (see chapter8, page 8-6)
 - closing of fuel tank cap
3. Left wing tip - check
 - surface condition
 - attachment check
 - fuel tank vent - cleanness
 - condition and attachment of the position lights and the anticollision beacon - if installed
4. Left aileron - check
 - surface condition
 - attachment
 - free movement
5. Left wing flap - check
 - surface condition
 - attachment
6. Rear part of fuselage - check
 - surface condition
 - condition of antennas (top and bottom fuselage surface) - if installed
7. Tail units - check



- tail skid condition
 - surface condition
 - condition of rudder and elevator attachment
 - freedom of rudder and elevator movement
 - condition of trim tab, condition of elevator trim tab control
8. Rear part of fuselage - check
- surface condition
9. Right wing flap- see 5.
10. Right aileron- see 4.
11. Right wing tip - see 3.
12. Right wing - see 2. except the landing light (if installed) and Pitot tube
13. Right landing gear leg - see 1.
14. Front part of the fuselage - right hand side - check
- tilting canopy attachment and condition
 - condition of the nose landing gear leg
 - nose wheel condition
 - condition of the nose wheel control rods
15. Engine
- Checks before the first flight of day - it is necessary to remove upper engine cowling:
- condition of engine bed
 - condition of engine attachment
 - condition of exhaust system
 - condition of engine cowlings
 - visual check on fuel and electrical system condition
 - check on cooling liquid volume in the expansion tank on the engine body
(replenish as required up to max. 2/3 of the expansion tank volume)

**AIRCRAFT OPERATING INSTRUCTIONS**Doc. No. SP2006AOIUS

Checks before every flight:

- cleanness of air intakes
- check on oil level (between marks - flattenings on the dip stick)
- check on cooling liquid level in the overflow bottle (level should be between min. and max. mark)
- proper closing of the upper cowling

16. Propeller - check

- attachment
- condition of blades, hub and spinner

17. Front part of fuselage - left hand side - check

- tilting canopy attachment and condition

18. Cockpit - check

NOTE

Turn handle clockwise to open cockpit. When keyway is in handle axis, cockpit is locked. Unlock it first with key to keyway perpendicular position to the handle axis.

- all switches OFF
- instrument equipment check on condition
- check on presence of loose object in the cockpit
- check on adjusting and securing the rudder pedals (see section 7.3.3) - if installed adjustable rudder pedals

WARNING

**RIGHT AND LEFT PEDAL OF RUDDER
CONTROL MUST BE SET TO THE SAME
POSITIONS AND WELL SECURED!**

Aircraft Operating Instructions
and other required documents

check on completeness
and validity



4.5 Normal procedures and checklist

4.5.1 Before engine starting

1. Pre-flight check and check on weight and centre of gravity position done
2. Safety harnesses check, fasten
3. Control stick free
4. Rudder pedals free
5. Wing flaps function check
6. Trim tab function check
7. PARKING BRAKE handle (if installed) release brakes
8. Brakes function check
9. **AVIONICS SWITCH** check OFF
10. Ignition check OFF
11. Canopy close

4.5.2 Engine starting

1. Master switch ON
2. Fuel gauge indicators check of fuel quantity
3. **FUEL SELECTOR LEFT**
Pull the safety button on the fuel selector, turn the handle to the left and then release safety button. Now the handle can be freely moved between left and right position. Safety button prevents unintentionally switch the selector to OFF position.
4. **Electric fuel pump (if installed)** ON
5. THROTTLE lever idle
6. Choke as necessary (open by pulling up and lock by turning)
7. Space in the propeller area free
8. BEACON (if installed) ON
(if necessary)
9. Brakes apply



10. Ignition

START (see CAUTION)
after starting up BOTH

CAUTION

ACTIVATE STARTER FOR 10 SEC. AS A MAXIMUM, THEN LET IT COOL DOWN FOR 2 MINUTES.

AFTER STARTING UP ENGINE, DO NOT CARRY OUT SUDDEN RPM CHANGES, AFTER POWER DECREASE WAIT FOR ABOUT 3 S IN ORDER TO REACH CONSTANT RPM BEFORE REACCELERATION.

- 11. THROTTLE lever as necessary (see NOTE)
- 12. Oil pressure up to 10s min. pressure
- 13. **GEN, AUX GEN** (if inst.) switches ON

NOTE

After starting up engine, adjust throttle for smooth engine running at about 2500 RPM. Check oil pressure. Pressure must increase within 10s. Increase engine RPM until oil pressure is stabilised over 2 bar (29 PSI).

- 14. Engine instruments check
- 15. Choke as necessary
- 16. Engine warming up see NOTE

NOTE

Begin warming up with engine running at 2000 RPM. for about 2 minutes, continue at 2500 RPM. Warming time depends on outside air temperature until oil temperature reaches 122 °F.

- 17. FUEL SELECTOR **RIGHT**
Verify proper engine feeding from the right tank for approx. 1 minute.
- 18. FUEL SELECTOR **LEFT**



NOTE

Start engine with the fuel selector set to **LEFT**.
If you would start the engine with the fuel selector set to **RIGHT** and the left tank is full, than fuel bleed from the left tank vent may occur (and pollute environment) because a fuel return hose is led only into the left tank and returning fuel will overfill the left tank.

- | | |
|--------------------------------|-----------------|
| 19. AVIONICS SWITCH | ON |
| 20. Radiostation/avionics | ON |
| 21. Other electrical equipment | ON as necessary |

4.5.3 Before taxiing

- | | |
|----------------------------------|--------------|
| 1. Transponder (if installed) | SBY |
| 2. Outside lights (if installed) | as necessary |

4.5.4 Taxiing

- | | |
|---|------------------------|
| 1. THROTTLE lever | as necessary |
| 2. Brakes | check by
depressing |
| 3. Rudder pedals | function check |
| 4. Direction of taxiing control by rudder pedals (these are mechanically connected with nose wheel control), possibly by slacking up left and right wheel of the main landing gear. | |

4.5.5 Before take-off

- | | |
|-------------------|------------------------|
| 1. Brakes | brake |
| 2. Ignition check | carry out,
see NOTE |

NOTE

Carry out ignition check in the following way :
Set engine speed to 4000 RPM. Switch ignition gradually to L, BOTH, R position and return to BOTH..
RPM drop with one ignition circuit switched off



AIRCRAFT OPERATING INSTRUCTIONS

Doc. No. SP2006AOIUS

must not exceed 300 RPM. Maximum RPM difference at using one of the L or R circuits is 120 RPM.

- | | |
|---|-------------------------|
| 3. Engine instruments | check |
| 4. Control stick | free |
| 5. Wing flaps | take-off pos. (15°) |
| 6. Trim | NEUTRAL |
| 7. Fuel gauge indicator | check on fuel quantity |
| 8. FUEL SELECTOR | check LEFT |
| 9. CARBURETTOR PREHEATER (if installed) | check function then OFF |

NOTE

If CARBURETTOR PREHEATER is switched ON, then engine RPM drop reaches approximately 50 RPM

- | | |
|--------------------------------|------------------------------|
| 10. Engine instruments | check |
| 11. Flight instruments | check |
| 12. Radiostation / avionics | check, set |
| 13. Ignition | check BOTH |
| 14. Choke | close (in inserted position) |
| 15. Master switch | check ON |
| 16. Safety harnesses | tighten up |
| 17. Canopy | closed |
| 18. Transponder (if installed) | ON or ALT |

4.5.6 Take-off

- | | |
|--|----------------------|
| 1. THROTTLE lever | max. take-off power |
| 2. During take-off run smoothly lighten up the nose landing gear until airplane take-off occurs. | |
| 3. Airspeed | 56 KIAS (65 mph IAS) |



- | | |
|---|--------------|
| 4. Brakes | brake |
| 5. After reaching 150 ft , set flaps to retracted pos. (0°) | |
| 6. Trim | as necessary |

WARNING

TAKE-OFF IS PROHIBITED:

- **IF ENGINE RUNNING IS IRREGULAR**
- **IF CHOKE IS OPEN**
- **IF VALUES OF ENGINE INSTRUMENTS ARE NOT WITHIN THE REQUIRED RANGE**

4.5.7 Climb

- | | |
|--------------------------------------|--|
| 1. THROTTLE lever | max. continuous power |
| 2. Airspeed | $V_Y = 63$ KIAS (73 mph IAS)
for the best rate of climb or
$V_X = 55$ KIAS (63 mph IAS)
for the best angle of climb |
| 3. Engine instruments | check |
| 4. Trim | as necessary |
| 5. Electric fuel pump (if installed) | OFF |



4.5.8 Cruise

- | | |
|-----------------------|-----------------------------|
| 1. THROTTLE lever | as necessary |
| 2. Airspeed | max. 103 KIAS (118 mph IAS) |
| 3. Engine instruments | check |
| 4. Fuel quantity | check |

CAUTION

FUEL GAUGES DISPLAY TRUE FUEL QUANTITY ONLY ON GROUND AND IN A LEVEL FLIGHT. TO READ TRUE FUEL QUANTITY AFTER TRANSITION FROM CLIMB/DESCENT WAIT APPROX. 2 MINUTES TO FUEL TO LEVEL.

NOTE

It is recommended to alternately switch the tanks during cruise to equally consume fuel from both tanks and minimize airplane tendency to bank with unbalanced tanks.

Do not fly with the fuel selector set to **RIGHT** if the left tank is full to avoid fuel bleed from left tank vent.

When the left tank fuel gauge indicates approx. 1/8 of fuel quantity (needle in the middle between 1/4 and 0) then switch to the right tank to consume remaining fuel and then switch back the left tank to complete the flight at left tank. If the engine conks out due to fuel consumption from either tank, then immediately switch the fuel selector to other tank and engine run will be recovered within 7 seconds.

5. CARBURETTOR PREHEATER (if installed) as necessary



4.5.9 Descent

1. THROTTLE lever as necessary
2. Airspeed as necessary
3. Trim as necessary
4. Engine instruments check
5. CARBURETTOR PREHEATER (if installed) as necessary

CAUTION

AT LONG APPROACHING AND DESCENDING FROM HIGH ALTITUDE IT IS NOT SUITABLE TO REDUCE THROTTLE TO MINIMUM FOR THE REASON OF POSSIBLE ENGINE UNDERCOOLING AND SUBSEQUENT LOSS OF POWER. PERFORM DESCENDING AT INCREASED IDLE AND CHECK OBSERVANCE OF THE ALLOWED VALUES ON ENGINE INSTRUMENTS.

4.5.10 Before landing

1. Fuel quantity check

CAUTION

FUEL GAUGES DISPLAY TRUE FUEL QUANTITY ONLY ON GROUND AND IN A LEVEL FLIGHT. TO READ TRUE FUEL QUANTITY AFTER TRANSITION FROM CLIMB/DESCENT WAIT APPROX. 2 MINUTES TO FUEL TO LEVEL.

2. FUEL SELECTOR **LEFT**
3. Engine instruments check
4. Brakes check by depressing pedals
5. Safety harnesses tighten up
6. Free area of landing check
7. CARBURETTOR PREHEATER (if installed) ON



- | | |
|----------------------------------|----------------------|
| 8. Approaching speed | 59 KIAS (68 mph IAS) |
| 9. Flaps | take-off pos. (15°) |
| 10. Trim | as necessary |
| 11. Parking brake (if installed) | check for lever down |

CAUTION

PARKING BRAKE MUST BE RELEASED
(LEVER DOWN) TO PREVENT LANDING WITH
BRAKED WHEELS

- | | |
|---------------------------------------|----|
| 12. Electric fuel pump (if installed) | ON |
|---------------------------------------|----|

FINAL

- | | |
|---|---------------------------|
| 1. Flaps | landing pos. (30° or 50°) |
| 2. Maintain airspeed | 60 KIAS (69 mph IAS) |
| 3. Trim | as necessary |
| 4. CARBURETTOR PREHEATER (if installed) | OFF |

4.5.11 Balked landing

- | | |
|----------------------|-----------------------|
| 1. THROTTLE lever | max. take-off power |
| 2. Flaps | take-off pos. (15°) |
| 3. Airspeed | 56 KIAS (65 mph IAS) |
| 4. Flaps in 150 ft | retracted pos. (0°) |
| 5. Trim | as necessary |
| 6. THROTTLE lever | max. continuous power |
| 7. Instruments | check |
| 8. Climb at airspeed | 63 KIAS (73 mph IAS) |

4.5.12 Landing

- | | |
|---|--------------|
| 1. THROTTLE lever | idle |
| 2. Touch-down on main landing gear wheels | carry out |
| 3. Brakes after nose landing gear
wheel touch-down | as necessary |



4.5.13 After landing

- | | |
|--------------------------------------|---------------------|
| 1. Flaps | retracted pos. (0°) |
| 2. Trim | NEUTRAL |
| 3. Outside lights (if installed) | OFF |
| 4. Transponder (if installed) | OFF |
| 5. Electric fuel pump (if installed) | OFF |

4.5.14 Engine shut-off

- | | |
|-------------------------------|-------|
| 1. THROTTLE lever | idle |
| 2. Engine instruments | check |
| 3. AVIONICS SWITCH | OFF |
| 4. Radiostation / avionics | OFF |
| 5. Other electrical equipment | OFF |
| 6. Ignition | OFF |
| 7. BEACON (if installed) | OFF |
| 8. Master switch | OFF |



4.5.15 Airplane parking

1. Ignition check OFF
2. Master switch check OFF
3. FUEL SELECTOR **OFF**
Pull the safety button on the fuel selector, turn the handle to the OFF position and then release safety button. Now the handle is blocked in the OFF position. Safety button prevents unintentionally switch the selector from the OFF position.
4. PARKING BRAKE handle (if installed) brake as necessary
5. Canopy close,
lock as necessary

NOTE

It is recommended to use parking brake (if installed) for short-time parking only, between flights during a flight day. After ending the flight day or at low temperatures of ambient air, do not use parking brake, but use the wheel chocks instead.



Intentionally left blank



CONTENTS

5.	PERFORMANCE	3
5.1	Introduction	3
5.2	Approved data	4
5.2.1	Airspeed indicator system calibration	4
5.2.2	Stall speeds	6
5.2.3	Take-off distance	7
5.2.4	Landing distance	7
5.2.5	Climb performance	8
5.3	Additional information	10
5.3.1	Cruise	10
5.3.2	Horizontal speeds	11
5.3.3	Endurance	12
5.3.4	Balked landing climb	13
5.3.5	Effect on flight performance and characteristics	14
5.3.6	Demonstrated crosswind performance	14
5.3.7	Ceiling	15
5.3.8	Noise data	15



Intentionally left blank



5. PERFORMANCE

5.1 Introduction

Section 5 provides data for airspeed calibration, stall speeds, take-off performance and nonapproved additional information, provided by the airplane type certificate owner.

The stated performance data has been computed from actual flight tests with the SPORTSTAR^{PLUS} airplane and ROTAX 912 ULS engine in good condition and using average piloting techniques.

CAUTION

THE PERFORMANCE STATED IN THIS SECTION IS VALID FOR ROTAX 912 ULS (100 HP) TOGETHER WITH WOODCOMP KLASSIC 170/3/R PROPELLER INSTALLED IN THE AIRPLANE, OTHERWISE SEE SECTION 9 - SUPPLEMENTS FOR ACTUAL PERFORMANCE.



5.2 **Approved data**

5.2.1 **Airspeed indicator system calibration**

NOTE

Assumed zero instrument error. Valid for airplane
take-off weight 1268 lbs .

Flaps deflection 0°		Flaps deflection 15°		Flaps deflection 50°	
CIAS	KCAS	CIAS	KCAS	CIAS	KCAS
				38	40
		41	43	40	41
43	45	43	44	43	44
45	47	45	46	45	46
50	51	47	48	47	47
55	55	50	50	50	50
60	60	53	53	53	53
65	64	55	55	55	54
70	68	57	57	57	56
75	73	60	59	60	59
80	77	63	62	63	62
85	81	65	64	65	63
90	86	67	66	67	65
95	90	70	68	70	68
100	95				
105	99				
110	104				
115	109				
120	113				
125	118				
130	122				
135	127				
140	132				
145	137				
146	138				

**AIRCRAFT OPERATING INSTRUCTIONS**

Doc. No. SP2006AOIUS

Flaps deflection 0°		Flaps deflection 15°		Flaps deflection 50°	
IAS [mph]	CAS [mph]	IAS [mph]	CAS [mph]	IAS [mph]	CAS [mph]
				44	46
		47	49	47	48
50	52	50	52	50	51
55	57	53	54	53	53
60	61	55	56	55	55
65	65	57	57	57	57
70	69	60	60	60	60
75	74	63	63	63	62
80	78	65	65	65	64
85	82	67	66	67	66
90	87	70	69	70	69
95	91	73	72	73	71
100	96	75	74	75	73
105	100	77	75	77	75
110	105	80	78	80	78
115	109	81	79	81	79
120	114				
125	118				
130	123				
135	127				
140	132				
145	137				
150	141				
155	146				
160	151				
165	155				
168	158				



5.2.2 Stall speeds

- Conditions:**
- wing level stall - engine at idle power
 - turning flight stall - engine at 75% max. continuous power
 - airplane weight: 1268 lbs

NOTE

The stated stall speeds are valid for all flight altitudes.

Altitude losses shown in the table present max. values determined on the basis of flight tests using average piloting technique.

575 kg	Flaps position	Stall speed		Altitude loss
1268 lb		KIAS	KCAS	ft
Wing level flight	Retracted (0°)	43	45	200
	Take-off (15°)	41	43	
	Landing (50°)	38	40	
Turn flight (coordinated turn 30° bank)	Retracted (0°)	46	49	200
	Take-off (15°)	44	46	
	Landing (50°)	41	43	

575 kg	Flaps position	Stall speed		Altitude loss
1268 lb		IAS [mph]	CAS [mph]	ft
Wing level flight	Retracted (0°)	50	52	200
	Take-off (15°)	47	49	
	Landing (50°)	44	46	
Turn flight (coordinated turn 30° bank)	Retracted (0°)	54	56	200
	Take-off (15°)	51	53	
	Landing (50°)	47	48	



5.2.3 Take-off distance

Conditions:

- engine: max. take-off power
- flaps: Take-off (15°)
- carburettor preheating: OFF
- airplane weight: 1268 lbs
- altitude: 0 ft ISA
- ambient air temperature: ISA

	Take-off run	Take-off distance to height of 50 ft (15 ft)
Dray concrete	620 ft	1440 ft
Grass	720 ft	1540 ft

Corrections:

- Influence of wind: Add 4% on every 1 kt (1.15 mph) of tail wind
- RWY inclination: Add 8% of the take-off run distance on 1% of runway inclination up the slope

5.2.4 Landing distance

Conditions:

- engine: idle
- flaps: Landing 50°
- carburettor preheating: OFF
- airplane weight: 1268 lbs
- altitude: 0 ft ISA
- ambient air temperature: ISA

	Landing distance from height of 50 ft (15 ft)	Braked landing run
Dray concrete	1310 ft	590 ft
Grass	1250 ft	520 ft

Corrections:

- Influence of wind: Add 4.5 % on every 1 kt (1.15 mph) of tail wind
- RWY inclination: Add 8% of the landing run distance on 1% of runway inclination down the slope




AIRCRAFT OPERATING INSTRUCTIONS

Doc. No. SP2006AOIUS

5.2.5 Climb performance

Conditions:

- engine: maximum take-off power
- flaps: retracted (0°)
- carburettor preheating: OFF
- airplane weight: 1268 lbs
- ambient air temperature: ISA



**AIRCRAFT OPERATING INSTRUCTIONS**Doc. No. SP2006AOIUS

Best rate of climb for various altitudes is mentioned in the following table:

Altitude	Best rate of climb speed		Maximum Rate of climb
Hp [ft ISA]	KIAS	IAS [mph]	[ft/min]
0	61	71	880
1000	61	70	820
2000	61	70	760
3000	61	70	710
4000	61	70	650
5000	60	69	590
6000	60	69	540
7000	60	69	480
8000	60	69	420
9000	59	68	370
10000	59	68	310



5.3 Additional information

5.3.1 Cruise

- Conditions:
- flaps:

- carburetter preheating:


- airplane weight:

- ambient air temperature:
- retracted (0°)

OFF

1268 lbs

ISA





AIRCRAFT OPERATING INSTRUCTIONS

Doc. No. SP2006AOIUS

5.3.2 Horizontal speeds

In the following table states Indicated airspeeds (IAS), corresponding calibrated air speeds (CAS) and true air speeds (TAS) versus altitude, all for various engine speeds.

		55% MTV	65% MTV	75% MTV	MCP Maximum Continuous Power	MTP Maximum Takeoff Power (5 min.)
		4300 rpm	4800 rpm	5000 rpm	5500 rpm	5800 rpm
0 ft ISA	KIAS	82	93	97	109	116
	KCAS	78	88	92	103	110
	KTAS	78	88	92	103	110
2000 ft ISA	KIAS	78	89	94	106	
	KCAS	75	85	90	100	
	KTAS	77	88	92	103	
4000 ft ISA	KIAS	74	86	91	103	
	KCAS	72	83	87	97	
	KTAS	76	88	92	103	
6000 ft ISA	KIAS	70	83	88	100	
	KCAS	69	80	84	95	
	KTAS	75	87	92	103	
8000 ft ISA	KIAS	66	80	85	96	
	KCAS	65	77	81	92	
	KTAS	73	86	91	103	
10000 ft ISA	KIAS	62	76	81		
	KCAS	62	74	78		
	KTAS	72	86	91		



5.3.3 Endurance

Conditions: -flaps: retracted (0°)
 - carburetter preheating: OFF
 - airplane weight: 1268 lbs
 - ambient air temperature: ISA


ENDURANCE AND RANGE		55% MCP	65% MCP	75% MCP	MCP Max.Continuous Power
Altitude 2000 ft ISA					
Engine speed	[rpm]	4300	4800	5000	5500
Fuel consumption	[l/h]	14,1	18,6	20,5	25,1
	[USgal/h]	3,7	4,9	5,4	6,6
	[UKgal/h]	3,1	4,1	4,5	5,5
IAS	[km/h]	144	166	174	196
	[knots]	78	89	94	106
	[mph]	90	103	108	122
CAS	[km/h]	139	158	166	185
	[knots]	75	85	90	100
	[mph]	86	98	103	115
TAS	[km/h]	143	163	171	191
	[knots]	77	88	92	103
	[mph]	89	101	106	119
Endurance at 120,0 l	[h:m]	8:30	6:26	5:50	4:46
Range at	120,0 l [km]	1220	1050	1000	910
	31,7 USGAL [NM]	659	567	540	491
	26,4 UKGAL [miles]	758	652	621	565
Endurance at 100,0 l	[h:m]	7:05	5:22	4:52	3:59
Range at	100,0 l [km]	1020	870	830	760
	26,4 USGAL [NM]	551	470	448	410
	22,0 UKGAL [miles]	634	541	516	472
Endurance at 75,0 l	[h:m]	5:19	4:01	3:39	2:59
Range at	75,0 l [km]	760	660	620	570
	19,8 USGAL [NM]	410	356	335	308
	16,5 UKGAL [miles]	472	410	385	354
Endurance at 50,0 l	[h:m]	3:32	2:41	2:26	1:59
Range at	50,0 l [km]	510	440	420	380
	13,2 USGAL [NM]	275	238	227	205
	11,0 UKGAL [miles]	317	273	261	236
Endurance at 25,0 l	[h:m]	1:46	1:20	1:13	0:59
Range at	25,0 l [km]	250	220	210	190
	6,6 USGAL [NM]	135	119	113	103
	5,5 UKGAL [miles]	155	137	130	118



5.3.4 Balked landing climb

Conditions:

- engine:	maximum take-off power
- carburettor preheating:	OFF
- flaps:	landing position (50°)
- airplane weight:	1268 lbs
- ambient air temperature:	ISA





5.3.5 Effect on flight performance and characteristics

Flight performances and characteristics are not considerably affected by rain or insect stuck on the airplane surface.

5.3.6 Demonstrated crosswind performance

Maximum demonstrated speed of wind at airplane operation	24 kts (28 mph)
Maximum demonstrated speed of cross wind for take-off and landing	10 kts (12 mph)
Maximum demonstrated speed of tail wind	6 kts (7 mph)




Figure 5-1 Influence of wind on take-off and landing

**AIRCRAFT OPERATING INSTRUCTIONS**Doc. No. SP2006AOIUS

5.3.7 CeilingService ceiling of SPORTSTAR^{PLUS} 13 030 ft**5.3.8 Noise data**

Not measured.



Intentionally left blank



CONTENTS

6.	<i>WEIGHT AND BALANCE</i>	3
6.1	Introduction	3
6.2	Weight and Balance Record.....	4
6.3	Permitted Payload Range	5
6.4	Operational Weight and Balance Computation.....	6
6.4.1	Computational Procedure.....	6
6.5	Airplane Loading Schedule Chart.....	8
6.6	Table of Static Moments	9
6.7	Airplane Loading Graph	10
6.8	CG Moment Envelope	11
6.9	Operational Weight and CG Envelope	12
6.10	Equipment List	13



Intentionally left blank



6. WEIGHT AND BALANCE

6.1 Introduction

This Section includes Weight and Balance Record of empty airplane, Permitted Payload Range within which the airplane may be safely operated, and a method to determine whether the operational weight and CG location will be within the permitted limits range.

Procedure for weighing the airplane and the calculation method for establishing the permitted payload range are contained in the Aircraft Maintenance and Inspection Procedures for the SPORTSTAR^{PLUS} Light Sport Aircraft.



6.2 Weight and Balance Record

[illegible]



6.3 Permitted Payload Range

Maximum weight of crew [lbs]											
Date	Empty weight [lbs]	C.G. [% MAC]	FUELLING						Approved		
			Fuel volume	1	0.8	0.6	0.4	0.2	Date	Signature	
			Fuel volume [U.S. gallons]	31.7	26.4	19.8	13.2	6.6			
			Fuel weight [lbs]	190	159	119	79	40			
			55 lbs								
			26 lbs								
			0 lbs								
			55 lbs								
			26 lbs								
			0 lbs								
			55 lbs								
			26 lbs								
			0 lbs								
			55 lbs								
			26 lbs								
			0 lbs								

B A G G A G E



6.4 Operational Weight and Balance Computation

An important part of preflight planning is to determine that the aircraft is loaded so its weight and CG location are within the allowable limits. This is possible by using hereafter explained Loading graph method, using weights, arms, and moment indexes.

6.4.1 Computational Procedure

1. Record into the **Airplane Loading Schedule Chart** current empty weight and static moment of the airplane, which you read from the table 6.2 Weight and Balance Record.
2. Record the weight of crew, fuel, and baggage into the **Airplane Loading Schedule Chart**.
3. See the **Table of Static Moments** or **Airplane Loading Graph** to read static moments for given weights of crew, fuel, and baggage
4. Record found moments into the **Airplane Loading Schedule Chart**
5. Determine Take-off weight of the airplane – add together the airplane empty weight, crew, fuel, and baggage and record the result into the **Loading Schedule Chart**.
6. Check, whether the calculated Take-off weight does not exceed Airplane Maximum Take-off Weight 1268 lb.
If yes, then it is necessary to reduce weight of some of the useful load items (fuel, baggage).

WARNING

**EXCEEDING MTOW MAY LEAD TO
DETERIORATION OF SAFETY OF FLIGHT!**

7. Determine Total Static Moment of loaded airplane – add together the static moment of empty airplane, crew, fuel, and baggage and record the result into the **Loading Schedule Chart**.
8. Plot Takeoff Weight and Total Static Moment into the **SPORTSTAR^{PLUS} CG Moment Envelope**.
9. Check, whether the intersection of Take-off weight horizontal line and Total Static Moment vertical line is inside the envelope.
If **YES**, then the flight may be safely performed as regards weight and balance.
If **NOT**, then it is necessary to change weight of some of the useful load items (crew, fuel, baggage) so that after a repeated

**AIRCRAFT OPERATING INSTRUCTIONS**Doc. No. SP2006AOIUS

computation the intersection of Take-off Weight and Total Static Moment will be inside the CG Moment envelope.

WARNING

**SAFETY OF FLIGHT PERFORMED WITH THE
AIRPLANE LOADED OUTSIDE PERMITTED
LIMITS OF WEIGHT AND STATIC MOMENTS
MAY BE DETERIORATED'!**



6.5 Airplane Loading Schedule Chart

Type / Model	SportStar plus	Serial No.:	2008 1102	Registration:	
--------------	----------------	-------------	-----------	---------------	--

Loading Schedule Chart							
Your Aircraft			Sample Aircraft			Your Aircraft	
No	Item	Arm * (in)	Arm (in)	Weight (lb)	Moment/100 (lb-in)	Weight (lb)	Moment/100 (lb-in)
1.	Empty Airplane		10,39 in	740,75 lb	77,1 lb-in		
2.	Crew	21,45 in		399,04 lb	85,6 lb-in		
3.	Baggage (Max. 55 lb)	42,65 in		11,02 lb	4,7 lb-in		
4.	Fuel (Max. 32 USGAL)	26,75 in		60,41 lb	16,2 lb-in		
5.	Take off weight = Sum of weights 1-4 (MTOW 1268 lb) Total moment = Sum of moments 1-4			1211 lb	184 lb-in		

*) – for your empty airplane arm see Weight and Balance Record delivered with your airplane




6.6 Table of Static Moments

CREW		BAGGAGE		FUEL		
Weight (lb)	Moment/100 (lb-in)	Weight (lb)	Moment/100 (lb-in)	Quantity (USGAL)	Weight (lb)	Moment/100 (lb-in)
0	0,0	0	0,0	0,0	0,0	0,0
100	21,5	2	0,9	1,0	6,0	1,6
120	25,7	4	1,7	2,0	12,0	3,2
140	30,0	6	2,6	3,0	18,0	4,8
160	34,3	8	3,4	4,0	24,0	6,4
180	38,6	10	4,3	5,0	30,0	8,0
200	42,9	12	5,1	6,0	36,1	9,6
220	47,2	14	6,0	7,0	42,1	11,3
240	51,5	16	6,8	8,0	48,1	12,9
260	55,8	18	7,7	9,0	54,1	14,5
280	60,1	20	8,5	10,0	60,1	16,1
300	64,4	22	9,4	11,0	66,1	17,7
320	68,6	24	10,2	12,0	72,1	19,3
340	72,9	26	11,1	13,0	78,1	20,9
360	77,2	28	11,9	14,0	84,1	22,5
380	81,5	30	12,8	15,0	90,1	24,1
400	85,8	32	13,6	16,0	96,1	25,7
420	90,1	34	14,5	17,0	102,1	27,3
440	94,4	36	15,4	18,0	108,2	28,9
460	98,7	38	16,2	19,0	114,2	30,5
480	103,0	40	17,1	20,0	120,2	32,2
500	107,3	42	17,9	21,0	126,2	33,8
520	111,5	44	18,8	22,0	132,2	35,4
540	115,8	46	19,6	23,0	138,2	37,0
560	120,1	48	20,5	24,0	144,2	38,6
		50	21,3	25,0	150,2	40,2
		52	22,2	26,0	156,2	41,8
		54	23,0	27,0	162,2	43,4
		55	23,5	28,0	168,2	45,0
				29,0	174,3	46,6
				30,0	180,3	48,2
				31,0	186,3	49,8
				32,0	192,3	51,4




6.7 Airplane Loading Graph






6.8 CG Moment Envelope





6.9 Operational Weight and CG Envelope



6.10 Equipment List

The equipment installed in the airplane of particular serial number is shown in the following Equipment list.

[illegible]

Section 6

Weight and Balance



AIRCRAFT OPERATING INSTRUCTIONS

Doc. No. SP2006AOIUS

[illegible]



CONTENTS

7.	<i>AIRPLANE AND SYSTEM DESCRIPTION</i>	3
7.1	Introduction	3
7.2	Airframe	3
7.2.1	Fuselage	3
7.2.2	Wing	3
7.2.3	Horizontal tail unit (HTU)	3
7.2.4	Vertical tail unit (VTU)	3
7.3	Control	4
7.3.1	Longitudinal control	4
7.3.2	Lateral control	4
7.3.3	Rudder control	4
7.3.4	Elevator trim tab control	4
7.4	Controls in cockpit	5
7.5	Instrument panel	5
7.6	Inside and outside marking and placards	5
7.7	Landing gear and brakes	6
7.7.1	Landing gear	6
7.7.2	Brakes	6
7.8	Seat and safety harnesses	6
7.9	Baggage compartment	6
7.10	Canopy	7
7.11	Power unit	7
7.11.1	General	7
7.11.2	Engine control	7
7.11.3	Engine instruments	8
7.11.4	Engine cooling system	8
7.11.5	Engine lubrication system	9
7.11.6	Engine intake system	10
7.11.7	Ignition system	10



7.12 Fuel system	10
7.12.1 Fuel tanks.....	10
7.12.2 Fuel selector	11
7.12.3 Fuel filter.....	11
7.12.4 Indication of fuel quantity	11
7.12.5 Fuel tank draining	12
7.13 Electrical system.....	13
7.13.1 Lighting.....	13
7.13.2 Electrical system scheme.....	13
7.14 Pitot-static system	14
7.15 Supplementary equipment	15
7.15.1 Ventilation and heating system.....	15
7.16 Navigation and communication equipment.....	15



7. AIRPLANE AND SYSTEM DESCRIPTION

7.1 Introduction

This section describes systems of the airplane and its operation. More detailed information on optional systems and equipment are available in section 9, Supplements.

7.2 Airframe

The airframe of SPORTSTAR^{PLUS} airplane is of semimonocoque structure consisting of metal reinforcement, frames and duralumin sheet skin.

7.2.1 Fuselage

The fuselage is of semimonocoque structure consisting of reinforcements and duralumin skin. Fuselage section is rectangular in the lower part and elliptic in the upper part. The fin is an integral part of fuselage. The cockpit for two-member crew is located in the middle part of the fuselage that is accessible after uncovering the single-piece organic glass canopy. The engine compartment in the front part of the fuselage is separated from the cockpit by the steel fire wall to which the engine bed is attached.

7.2.2 Wing

The wing is of rectangular shape, single-spar structure with the auxiliary spar with suspended ailerons and split wing flaps. Riveting is used for connecting individual structural elements. Fiber-glass wing tips are riveted on the wing ends.

7.2.3 Horizontal tail unit (HTU)

The VTU of conventional type consists of the stabilizer and elevator with the trim tab. Single-spar structure of HTU consists of duralumin ribs, spar and skin. Top view of HTU is of rectangular shape.

7.2.4 Vertical tail unit (VTU)

VTU is of trapezoidal shape. Its fin is an integral part of the fuselage. The rudder is suspended on the fin by means of two hinges. The VTU structure consists of the duralumin spar and skin.



7.3 Control

Airplane control consists of ailerons, elevator and rudder. Directional control is connected by means of pull rods with nose landing gear control. Main landing gear brakes are controlled by pedals of directional control.

Airplane is equipped with dual control enabling flight with two-member crew.

7.3.1 Longitudinal control

Longitudinal control is actuated by the control stick. Longitudinal movement of control stick is transferred to the elevator by mechanical system of pull rods and levers.

7.3.2 Lateral control

Lateral control is actuated by the control stick. From the control stick the movement is transferred through the system of levers and pull rods to ailerons.

7.3.3 Rudder control

Rudder control is controlled by pedals of foot control. The rudder is interconnected with foot control pedals by cable system.

Foot control pedals adjustable into three positions can be installed as an option.

Way of adjustment of ruder pedals:

1. Release the pin from the adjusting groove
2. Set pedal to one of three possible positions
3. Check on the pin locking-on in the adjusting groove

WARNING

**RIGHT AND LEFT PEDAL OF RUDDER
CONTROL MUST BE ADJUSTED IN THE
SAME POSITIONS AND SECURED!**

7.3.4 Elevator trim tab control

The elevator trim tab is controlled by the lever located in between the pilot seats. The control lever is interconnected with the trim tab by means of bowdwen-cables.



7.4 Controls in cockpit




Figure 7-1 Cockpit control elements

- | | |
|--|--|
| 1. Control stick | 8. Choke |
| 2. Instrument panel | 9. Master switch |
| 3. Carburettor pre-heating knob
(if installed) | 10. Fuel selector |
| 4. Cockpit heating / canopy defog
selector (if installed) | 11. Rudder control pedals |
| 5. Hot air supply knob (if installed) | 12. Emergency parachute
system lever (if installed) |
| 6. Throttle lever | 13. Flaps control lever |
| 7. Ignition | 14. Trim control lever |
| | 15. Headset sockets |

7.5 Instrument panel

See section 9 - supplements.

7.6 Inside and outside marking and placards

See Aircraft Maintenance and Inspection Procedures.



7.7 Landing gear and brakes

7.7.1 Landing gear

The airplane is equipped with a sort of fixed nose landing gear. Main landing gear legs are produced from composite spring. Nose landing gear leg is welded from two pieces - the tube and the yoke- in which the nose wheel is mounted. The nose landing gear is spring-loaded by a rubber rope. The nose wheel is steerable, wheel control is coupled with rudder control by means of two pull rods. Wheels can be fitted with fiber-glass aerodynamic pants.

7.7.2 Brakes

The SPORTSTAR^{PLUS} airplane is equipped with disk hydraulic brakes on main landing gear wheels. Brake system is composed of brake pedals (these are a part of rudder control pedals), brake pumps, hoses for leading brake liquid, brake yokes with wheel cylinders and brake pads. By depressing the brake pedals compression of brake pumps occurs, which generates pressure in brake circuit and hydraulic cylinders press the brake pads onto the brake disks. Braking pressure can be regulated only by force of brake pedals depressing.

The airplane can be equipped by mechanical manually controlled parking brake. PARKING BRAKE handle is located in between the pilot seats.

7.8 Seat and safety harnesses

SPORTSTAR^{PLUS} is a two-seat airplane with side-by-side seats. Seats are fixed, non-adjustable and fitted with light upholstery.

Each of seats is fitted with four-point safety harness which is composed of safety belts, shoulder straps and lock. The safety harness is anchored in the middle of the frame behind the baggage compartment and on the seat sides.

7.9 Baggage compartment

Baggage compartment is positioned behind seat rests. Maximum weight of baggage is 55 lbs (25 kg) and is stated on the placard in the baggage compartment. The baggage compartment is fitted with rubber straps for baggage fixation.



7.10 Canopy

The cockpit canopy is of a semidrop shape. The framework is composed of metal structure on which the organic glass canopy is fixed by bolts.

The canopy is attached to the fuselage in the front part by two swivel pins by means of which it can be folded up forwards. In order to make opening easier, the actual weight of canopy is balanced by two gas struts, besides the canopy is provided with holders on the lower framework for easier handling. The canopy is provided with the lock in the rear upper part of framework for locking.

7.11 Power unit

7.11.1 General

The engine ROTAX 912 ULS (100 hp) is used to power SPORTSTAR^{PLUS} airplane.

ROTAX 912 ULS is a four-cylinder, four-stroke engine with opposite cylinders, central cam shaft and OHV valve mechanism.

The on-ground adjustable, composite, 3-blade propeller WOODCOMP KLASSIC 170/3/R. is standardly mounted on the engine ROTAX 912 ULS. Other propeller type can be installed on customer's request - see sec. 9 for detailed information .

7.11.2 Engine control

Engine power is controlled by means of THROTTLE lever, which is located in the middle of the instrument panel and which controls engine power range from idle up to maximum take-off . Engine power controller is mechanically interconnected with the flap on carburetters.

If the lever is fully pushed in, then this position corresponds to maximum engine power. If the lever is fully pulled out, then this position corresponds to idle. Rapid changes in engine power setting can be made by pressing down the round button on the lever body and by its pulling out or pushing in. Small changes in power setting can be performed through lever turning (counterclockwise - power increase).

The lever is fitted with the locking ring, counterclockwise turning of which ensures locking of the lever in requested position.



7.11.3 Engine instruments

The following analog instruments located on the instrument panel serve for engine performance monitoring. The digital engine monitoring system can be installed in the airplane instead of analog engine instruments.

RPM indicator

The electrical RPM indicator is controlled by signal from the generator RPM transmitter. Working range of the RPM indicator is 0 - 7000 RPM.. Colour code is stated in section 2.

Cylinder head thermometer

The cylinder head thermometer transmitter senses temperature of cylinder No. 3. Working range of the cylinder head thermometer is 120 ÷ 300°F. Colour code is stated in section 2.

Oil thermometer

Oil temperature on engine input is measured by the sensor located behind the oil pump. Working range of oil thermometer is 120 ÷ 300°F. Colour code is stated in section 2.

Oil pressure gauge

Oil pressure on the oil input into engine is measured by means of sensor which is located behind the oil filter. Working range is 0 ÷ 150 PSI. Colour code is stated in section 2.

7.11.4 Engine cooling system

Engine cooling is combined, cylinder heads are cooled by water, cylinders are cooled by air.

Cooling circuit of cylinder heads is designed as a closed system containing pump, expansion reservoir (1) with pressure closure (3), cooler of cooling liquid (2) and drainage reservoir (4). Scheme of cylinder head cooling system is shown in Fig. 7-2.

When changing, the cooling liquid is filled up through the cap of expansion reservoir (1), during airplane operation it is replenished into drainage reservoir (4) between the lines of maximum and minimum level.




Figure 7-2 Scheme of cylinder head cooling system

7.11.5 Engine lubrication system

Engine lubrication system is performed with the dry crank case. Engine lubrication system is equipped with oil pump (1) ensuring oil feeding from reservoir (4) located on the fire wall through the oil cooler (5) and the oil cleaner (6) to the lubricated points of engine. The pressure sensor (2) is located behind the oil pump. The oil reservoir is aerated by the hose (7) which is led under the airplane. Oil pressure and temperature are indicated on instruments in right side of the instrument panel. Oil is replenished through the lid in the upper part of the oil reservoir.




Figure 7-3 Scheme of engine lubrication system



7.11.6 Engine intake system

Engine intake system ensures delivery of sufficient air into engine. Air is taken into the engine through openings on the engine covers through the air filters.

The intake system can be equipped with carburettor heating system. Hot air from the heat exchanger (located on the exhaust collector) is taken to the mixing chamber. Amount of in-taken hot air is regulated by flaps in mixing chamber inlets. Flaps are controlled by the CARBURETTOR PREHEATER knob on the instrument panel.

7.11.7 Ignition system

The engine is equipped with the double contactless ignition system. Each ignition circuit has own source of energy, control unit, 2 ignition coils and 4 spark plugs. It is fully autonomous on the other circuit of accumulator. High voltage current is distributed to the spark plugs through high-voltage cables. Ignition sequence of individual engine cylinders:

Ignition circuits are controlled by the ignition switch on the instrument panel.

Positions of ignition switch:

OFF	engine ignition is off
R	only ignition circuit B is on
L	only ignition circuit A is on
BOTH	both circuits are on
START	both circuits are on and starter is cranking the engine

7.12 Fuel system

Fuel system serves for keeping fuel in the airplane and its feeding to the engine. Fuel system of SPORTSTAR^{PLUS} airplane is composed of integral fuel tanks, fuel line, fuel selector, fuel filter, mechanical fuel pump - located on the engine (auxiliary electrical fuel pump can be installed), distribution pipe of fuel with, return branch of fuel, fuel gauges and fuel tanks draining valves.

7.12.1 Fuel tanks


Fuel is contained in the wing integral tanks having volume 15.85 U.S. gallons each. Each tank is fitted with air venting (output is under the wing tip) and draining valve on the bottom side of the wing. Fuel is led from the tanks through the hoses to the fuel



selector located on a central console under the instrument panel and then through a fuel filter to the engine pump and carburetors. Fuel return hose goes from the fuel pump into the left tank, which is due to be considered as a “primary” tank. See figure 7-4 for Scheme of fuel system.

7.12.2 Fuel selector

The fuel selector serves for tank selection and fuel delivery interruption in case of engine fire or long parking of airplane. To move selector from OFF (closed) position it is necessary to pull the safety button on the fuel selector, turn the handle from the OFF position to the left and then release the safety button. Now the handle can be freely moved between LEFT and RIGHT position. The safety button prevents unintentional switching of the selector to the OFF position. To move the selector to the OFF (closed) position it is necessary to pull the safety button on the fuel selector, turn the handle to the OFF position and then release the safety button. Now the handle is blocked in the OFF position. The safety button prevents unintentional switching of the selector from the OFF position during parking.



7.12.3 Fuel filter

The fuel filter separates all mechanical impurities from fuel. The fuel filter is located in the cockpit on the left airframe panel.

7.12.4 Indication of fuel quantity

Fuel quantity is measured by a float fuel gauge transmitter in each tank and indicated on the fuel gauge on the instrument panel. The LH fuel gauge indicates fuel quantity in the left (primary) tank, the RH indicator in the right tank. True fuel quantity is indicated only on ground and



in level flight and it takes approx. 2 minutes to level fuel after transition from climb/descent.

7.12.5 Fuel tank draining

Draining of the fuel tank is specified in chapter 8.




Figure 7-4 Scheme of fuel system



7.13 Electrical system

The airplane is equipped with 14 V DC electrical installation. A generator with power of 250 W is the primary source of electrical energy. The secondary source of energy is the accumulator 12V/16Ah that is located in the engine compartment on the fire wall. It is used for engine starting and in case of generator failure as an emergency source of energy and also serves as the smoothing filter of power system.

DC voltage is distributed to individual systems by main busbar. Each system is protected by circuit breaker. If overloading of any of the circuits occurs, then the circuit breaker is pulled out. Circuit breakers are listed in the Aircraft Maintenance and Inspection Procedures.

CAUTION

DO NOT USE CIRCUIT BREAKERS FOR
NORMAL SWITCHING OFF OF THE SYSTEMS

After switching **MASTER SWITCH** on and by turning the ignition key to **START** position the starter is activated. The starter is power supplied from the accumulator before engine start. After engine has been started and idle RPM reached, generator starts supplying current into electrical network.

7.13.1 Lighting

Airplane can be equipped with a external lighting.

External lighting can be composed of position lights and anticollision beacons which are located in wing tip and landing headlight which is located in left wing leading edge or in the lower engine cowling. Position lights are switched by **POS. LIGHTS** switch and anticollision beacon by **BEACON** switch. Landing headlight is switched by **LDG LIGHT** (or **REFLECTOR**) switch.

7.13.2 Electrical system scheme

See Aircraft Maintenance and Inspection Procedures - Supplements.



7.14 Pitot-static system

Pitot-static tube for sensing static and total pressure is located under the left half of the wing. Total pressure is sensed through the opening in the Pitot-static tube face. Static pressure is sensed through openings on the tube circumference. System of pressure distribution to individual instruments are made by means of flexible plastic hoses. Transparent draining reservoirs are located in the pressure branch of static and total pressure on the left fuselage side by the wing leading edge.

Static pressure is led to altimeter, airspeed indicator, variometer and altitude encoder (if installed). Total pressure is led only to the airspeed indicator.




Figure 7-5 Scheme of pitot-static system



7.15 Supplementary equipment

7.15.1 Ventilation and heating system

Cockpit ventilation is ensured by two sliding windows located on the tilting canopy.

Cockpit heating is ensured by hot air from the heat exchanger. The heat exchanger is located on the exhaust pipe collector. Air from outside atmosphere is warmed up in the exhaust pipe collector and delivered through air hoses into the cockpit. Hot air quantity is regulated by the flap which is controlled by the **HOT AIR** knob on the instrument panel. The cockpit heating system can be equipped with a windshield blowing system.

7.16 Navigation and communication equipment

Description of operation of navigation and communication equipment see section 9 - Supplements.



Intentionally left blank



CONTENTS

8.	<i>AIRPLANE HANDLING SERVICING AND MAINTENANCE</i>	3
8.1	Introduction	3
8.2	Airplane inspection period	4
8.3	Modifications or airplane repairs	5
8.4	Road transport	5
8.4.1	Airplane towing	5
8.4.2	Airplane parking.....	6
8.4.3	Airplane anchoring.....	6
8.4.4	Airplane jacking.....	7
8.4.5	Levelling	7
8.4.6	Road transport	7
8.5	Draining of fuel tank	7
8.6	Cleaning and care	8

Section 8

Airplane Handling,
Servicing and
Maintenance



AIRCRAFT OPERATING INSTRUCTIONS

Doc. No. SP2006AOIUS

Intentionally left blank



8. AIRPLANE HANDLING SERVICING AND MAINTENANCE

8.1 Introduction

This section includes the procedures for airplane handling, maintenance and operation recommended by the manufacturer.

It is necessary to follow the set-down lubrication plan, scope and periodicity of preventive maintenance depending on climatic and flight conditions according to the Aircraft Maintenance and Inspection Procedures of SPORTSTAR^{PLUS} Light Sport Aircraft

Airplane owner should be in a permanent touch with the manufacturer, either directly or through the network of business representatives, which enables him to get the newest information concerning airplane operation, handling and maintenance. The manufacturer distributes this information to users through Service bulletins (Mandatory bulletins), Information bulletins (letters) and further instructions.

Mandatory bulletins are especially important for keeping up airworthiness and the manufacturer considers them mandatory although they do not come into effect before Airworthiness Directive is issued by aviation authority of user's country.

All correspondence with the airplane manufacturer, distributor or service center must contain **the airplane serial number**. The airplane serial number is shown on the title sheet of this Instructions and on the production plate behind the rest of pilot seats.

The manufacturer delivers along with aircraft SPORTSTAR^{PLUS} the "Aircraft Operating Instructions (AOI)" and the "Aircraft Maintenance and Inspection Procedures (AMIP)".

Qualification requirements to perform maintenance and repairs are mentioned in the AMIP - item 4.1.1.

Owner/Operator Responsibilities:

- Each owner/operator of an LSA airplane shall read and comply with the maintenance and continued airworthiness information and instructions provided by the manufacturer.

Section 8

Airplane Handling,
Servicing and
Maintenance



AIRCRAFT OPERATING INSTRUCTIONS

Doc. No. SP2006AOIUS

- Each owner/operator of an LSA airplane shall be responsible for providing the manufacturer with current contact information where the manufacturer may send the owner/operator supplemental notification bulletins.
- The owner/operator of an LSA airplane shall be responsible for notifying the manufacturer of any safety of flight issue or significant service difficulty upon discovery.
- The owner/operator of an LSA airplane shall be responsible for complying with all manufacturer issued notices of corrective action and for complying with all applicable aviation authority regulations in regard to maintaining the airworthiness of the LSA airplane.
- An owner of an LSA airplane shall ensure that any needed corrective action must be completed as specified in a notice, or by the next scheduled annual inspection.
- Should an owner/operator not comply with any mandatory service requirement, the LSA airplane shall be considered not in compliance with applicable ASTM Standards and may be subject to regulatory action by the presiding aviation authority.

8.2 Airplane inspection period

Periodical inspections and reviews of airplane must be carried out at the latest in the following intervals:

- after first 25 ± 2 hours of operation
- after every 50 ± 3 hours of operation
- after every 100 ± 5 hours of operation
- annual inspection

Details on periodical inspections are provided in the Aircraft Maintenance and Inspection Procedures of SPORTSTAR^{PLUS}.

Refer to the Rotax 912 Operator's Manual for engine maintenance.
Refer to the Propeller Maintenance Manual for propeller maintenance.



8.3 Modifications or airplane repairs

All airplane repairs and modifications of airplane must be carried out by qualified personnel in an approved service center (see AMIP - item 4.1.1.).

Before any repairs/modification is made to the aircraft, consult the Civil aviation authority of the country in which the airplane is registered to assess effect of the repair/modification on the airworthiness.

Basic repairs of airplane are described in the Aircraft Maintenance and Inspection Procedures of SPORTSTAR^{PLUS}.

8.4 Road transport

8.4.1 Airplane towing

It is possible to move the airplane on a short distance by holding the fuselage end in the position before the fin, eventually by holding the root part of wings.

The hand towing bar can be used for airplane relocation which will be fastened to the nose wheel axis.

To turn the airplane on the spot, push on the fuselage end part in the area before the fin, lift the nose wheel and turn the airplane in required direction.

WARNING

**SWITCH OFF IGNITION BEFORE GROUND
HANDLING WITH THE AIRPLANE!**

CAUTION

**AVOID EXCESSIVE PRESSURES ON THE
AIRFRAME STRUCTURE, ESPECIALLY ON
THE WING TIPS, HTU, VTU ETC.**

**WHEN HANDLING THE AIRPLANE BY MEANS
OF THE TOWING BAR, PROPELLER BLADES
MUST BE SET TO HORIZONTAL POSITION.**

Section 8

Airplane Handling,
Servicing and
Maintenance



AIRCRAFT OPERATING INSTRUCTIONS

Doc. No. SP2006AOIUS

MAXIMUM DEFLECTION OF THE NOSE
WHEEL IS $\pm 10^\circ$.

AT MANUAL ENGINE STARTING GRASP THE
PROPELLER BLADE AREA, I.E. NOT ONLY
PROPELLER EDGE.

8.4.2 Airplane parking

It is the most suitable solution to place the airplane into a hangar possibly into another covered room with stable temperature, good venting, low humidity and dust-free environment. In case of parking out of the hangar it is necessary to anchor the airplane and at long-term parking to cover the canopy, possibly the whole airplane with suitable tarpaulins.

8.4.3 Airplane anchoring

The airplane is anchored at parking out of hangar after termination of flight day or according to need. Anchoring of the airplane is necessary for its protection against possible damage, caused by wings and gusts. For this purpose the airplane is equipped with fixing eyes on the lower side of wings.

Procedure:

1. Check of fuel selector, off-position of all switches, ignition and master switch.
2. Lock manual control, e.g. by using safety belts
3. Close vent windows
4. Close and lock the cockpit canopy
5. Anchor the airplane to the ground by means of cables pulled through fixing eyes which are located on the lower side of wings. Further it is necessary to anchor the nose landing gear.

NOTE

In case that long-term airplane anchoring is supposed, namely in winter period, it is suitable to cover the canopy, eventually the whole airplane by appropriate tarpaulins which must be properly secured to the airplane structure.



8.4.4 Airplane jacking

Airplane jacking presents no big difficulties due to relatively low airplane empty weight and can be performed by two persons.

First, it is necessary to prepare two suitable rests which will support the airplane.

The airplane can be jacked in the following way:

- by pushing from the above to the fuselage rear part in the position before the fin the front part of fuselage can be jacked and subsequently supported under the fire wall.
- Rear part of fuselage can be slightly jacked only by grasping in the position near the auxiliary skid and by pushing from below and then the lower part of fuselage can be supported by the rest located in the area of the skid.
- Wings can be jacked by pushing on the wing from below in the area of the main spar. It is necessary to avoid jacking by grasping the wing tip.

8.4.5 Levelling

Levelling procedure is described in the Maintenance manual for SPORTSTAR^{PLUS} airplane.

8.4.6 Road transport

The airplane can be transported on communication after its loading on an appropriate trail. It is necessary to dismount wings. The airplane must be secured against possible movement. This way you will preclude possible damage to the airplane.

8.5 Draining of fuel tank

Draining should be done prior to first flight each day. There is a drain valve of each wing tank located on its bottom.

Procedure:

1. Put a transparent cup under the drain valve.
2. Using screwdriver (or appropriate jig) press and turn drain valve counterclockwise to open it.
3. Drain required quantity of fuel.

Section 8

Airplane Handling,
Servicing and
Maintenance



AIRCRAFT OPERATING INSTRUCTIONS



Doc. No. SP2006AOIUS

NOTE

Draining serves to elimination of impurities and deposits from the fuel. Drain until clean fuel flows from the drain valve.

4. Using screwdriver (or appropriate jig) turn drain valve clockwise to close it.
5. Repeat procedure for the opposite tank.

8.6 Cleaning and care

Always use appropriate cleaning agents when cleaning airplane surface. Residuum of oil and fat can be removed from the airplane surface (excluding the canopy) by suitable detergents, possibly by petrol.

The canopy only to be cleaned by washing with ample stream of tepid water with addition of appropriate detergents. Use soft rag, sponge or wash leather. Use suitable polishing agent after wiping rests of water.

CAUTION

NEVER DRY-CLEAN THE CANOPY AND
NEVER USE PETROL NOR CHEMICAL
SOLVENTS!

Coating, upholstery and carpets in the cockpit can be removed from the cockpit, brushed and, if need be, cleaned with warm water with addition of appropriate detergent. Dry up upholstery after doing this.



9. SUPPLEMENTS

9.1 Introduction

This section contains the appropriate supplements necessary to safely and efficiently operate the airplane when equipped with various optional systems and equipment not provided with the standard airplane.

9.2 List of inserted supplements

Inst.	Date	Doc. No.	Title of inserted supplement
	Dec 20/06	SP2006AOIUSS01	Transceiver KY97A
	Dec 20/06	SP2006AOIUSS02	Intercom PM 1000
	Dec 20/06	SP2006AOIUSS03	Transponder KT76A
	Dec 20/06	SP2006AOIUSS04	Airplane description of S/N
	Dec 20/06	SP2006AOIUSS05	GPS/COMM receiver KLX 135
	Dec 20/06	SP2006AOIUSS06	Flight clock LC-2
	Dec 20/06	SP2006AOIUSS07	Transceiver FILSER ATR 600
	Dec 20/06	SP2006AOIUSS08	GPS/NAV/COMM receiver GARMIN GNS 430/430A
	Dec 20/06	SP2006AOIUSS09	Transponder ATC GARMIN GTX 327
	Dec 20/06	SP2006AOIUSS010	Intercom PCD7100-I (PS ENGINEERING INCORPORATED)
	Dec 20/06	SP2006AOIUSS011	Rocket activated parachute rescue system Magnum Speed Soft 650
	Dec 20/06	SP2006AOIUSS012	Horizon RCA 26
	Dec 20/06	SP2006AOIUSS013	Float operation CZAW 1150
	Dec 20/06	SP2006AOIUSS014	Horizon LUN 1202
	Dec 20/06	SP2006AOIUSS015	Towing gear
	Dec 20/06	SP2006AOIUSS016	Pitot tube heating
	Dec 20/06	SP2006AOIUSS017	Emergency Locator Transmitter AK-450
-	-	SP2006AOIUSS018	Not used
	Dec 20/06	SP2006AOIUSS019	Stall warning system ACI type T1b
	May 11/07	SP2006AOIUSS019	Night VFR operation



AIRCRAFT OPERATING INSTRUCTIONS

Doc. No. SP2006AOIUS

[illegible]



AIRCRAFT OPERATING INSTRUCTIONS

Doc. No. SP2006AOIUS

9.3 Supplements inserted



Intentionally left blank